



Amari Tracking Force Gauge Operation Manual

AMARI Audio equipment co.,LTD

www.amari.cc

Email: amari@vip.163.com



Operation Manual






Thank you very much for purchasing Armani Tracking Force Gauge Manual.

Please read this manual carefully before use.

I. Operations:

1. Press the [] key, waiting for the scale to display “zero”.
2. Put the item to be weighted on the scale. When “0” is display on left, you can read the data.
3. You can switch weighting units using the [MODE] key.
4. Press [TARE] key to wait till “0.0” is display.
5. Press the [] key to turn the unit off.

II. Calibrations (only when needed):

1. Press the [] key, waiting for the scale to display “zero”.
2. Press and hold the [] key until the display shows “0”, then release it. The display will be blinking.
3. Put the calibration weight on the scale. After a few minutes, the unit will stop blinking, the back light will be brighter and then the weight will be displayed.
4. Calibration is completed now and press the [] key to turn the unit off.

Specifications:

- Range: 0-5g
- Precision: ± 0.01 g
- Weighting Modes: g/oz/ozt/TL/ct
- Calibration: Auto calibration using a 5g weight
- Auto off timer: 120 seconds
- Operation Temp: 0-40 °C
- Display: 4 digits LCD
- Battery: 2 x 1.5V Lithium Battery, AG12
- Dimensions: 96x43x20mm
- Weight: about 50g